

SONIC BLINK RECEIVER MODEL BL300

America's Leader in Visual Alerting Systems.



Sonic Alert



SONIC ALERT'S LIMITED WARRANTY

The Sonic Blink Receiver, Model BL 300 is warranted against manufacturing defects in materials and workmanship for five (5) years from the date of purchase. Within this period Sonic Alert will repair or replace at our option the BL 300 without charge for parts or labor. Simply send the BL 300 and a copy of your dated sales slip as proof of purchase to:

Sonic Alert Inc., 1050 East Maple Rd., Troy MI 48083

OPERATION

The Sonic Blink Receiver BL 300 will alert you by flashing a strobe light when a signal is received from a Sonic Alert Transmitter (Telephone Ring Signalers, Baby Cry Signaler or Doorbell Signaler). A Signal from one or all of the transmitters will be received by the BL 300 and in turn will flash the strobe light. The BL 300 will have a different sequence of flashing depending on which transmitter is being activated.

INSTALLATION

1. Plug the BL 300 Sonic Blink Receiver into any standard electrical outlet. Note the plug orientation.

WARNING

There are no user Serviceable parts inside. Do not try replacing the tube or modifying the unit.

BL 300 Installation

1. Plug BL 300 into wall outlet.



Made in China

Sonic Alert, Inc
1050 East Maple Rd., Troy MI 48083
(248)577-5400 www.sonicalert.com